

Model


G23

G33

G43

Compressed Air Systems

2626 Skyway Dr.
Grand Prairie, Texas 75052
1-800-531-9656 or 972-352-6363
Fax 972-352-6364
www.compressed-air-systems.com



G23-33-43 parts

When ordering parts use the pump model before the part

VALVES & UNLOADERS

1. 31010 Inlet valve seat
2. 31020 Inlet valve receiver
3. 31030 Inlet & outlet valve plate
4. 51070 Inlet valve spring
5. 31070 Inlet valve unloading fork guide
6. 11230 Unloading spring
7. 31080 Inlet valve unloading fork
8. 92517 Slotted nut
10. 41010 Outlet valve seat
11. 41020 Outlet valve receiver
12. 41070 Outlet valve spring
13. 41810 Outlet valve bolt
14. 92502 Nut (Outlet valve)
15. 11151 Inlet valve push cover
16. 93602 O-ring G #40
17. 93602 Viton O-ring G#40 (Outlet valve)
18. 11220 Unloading piston
19. 93601 O-ring P#20
20. 11450 Outlet valve push cover

CYLINDERS

21. 11010 Cylinder head (1st)
22. 11020 Cylinder & head packing
23. 51011 Cylinder (1st)
24. 51030 Cylinder & case packing
25. 61030 Compression ring (1st)
26. 61050 Oil control ring (1st)
27. 61010 Piston (1st)
28. 61070 Piston pin snap ring
29. 61120 Piston pin (1st)
30. 61080 Connecting rod piston pin bush (1st)
31. 61200 Connecting rod assembly
32. 61090 Connecting rod crank pin metal
33. 61250 Connecting rod bolt
34. 61281 Oil splash dipper
35. 91505 Oil splash dipper bolt
36. 12010 Cylinder head (2nd)
37. 52010 Cylinder (2nd)
- 91501 Cylinder head bolt
- 62030 Compression ring (2nd)
- 62050 Oil control ring (2nd)
- 62010 Piston (2nd)
- 62120 Piston pin (2nd)

CRANKCASE & CRANK ASSEMBLY

38. 56010 Crankshaft
39. 56030 Crankshaft counterweight
40. 56830 Counterweight lock washer
41. 56810 Counterweight mounting bolt
42. 57010 Crankcase
43. 57030 Front bearing cover
44. 57040 Front bearing cover packing
45. 57060 Rear bearing cover
46. 57070 Rear bearing cover packing
47. 93501 Front bearing
48. 93501 Rear bearing
49. 57080 Front oil seal
50. 56060 V-pulley pin
51. 76010 Compressor pulley
52. 76210 Compressor pulley washer
53. 92501 Compressor pulley set bolt
54. 57720 Gauge cover
55. 57730 Gauge cover seal
56. 57190 Crankcase oil cap
57. 90112 Crankcase oil plug
58. 57670 Breather body
59. 93901 Breather ball
60. 57610 Breather cap
61. 92513 Air strainer nut
62. 9252 Air strainer washer
63. 66170 Air strainer cover
64. 66140 Air strainer filter
65. 66010 Air strainer body
67. 66030 Air Strainer Joint
68. 87020 Outlet pipe joint #B
69. 87100 Compressor body discharge piping ass'y
70. 87010 Outlet pipe joint #A
71. 87010 Outlet pipe joint #D
72. 79922 Connecting ring nut
73. 79921 Connecting ring
74. 79927 Tee (unloading)