





CA1



L.P. INTAKE VALVE
L.P. INTAKE VALVE
L.P. EXHAUST VALVE
H.P. INTAKE VALVE
H.P. EXHAUST VALVE



						41	136-0046	722005	Valve Safety 70 PSI	1
1	049-0027	708000	Crankcase	1		42	082-0012	706000	Intercooler	1
2	053-0051	709000	Crankshaft	1		43	083-0009	706002	Elbow Aftercooler	1
3	051-0053	050170	Bearing Set Front	1		44	031-0057	704000	Elbow Valve and Unloader	1
4	045-0044	701000	Front Bearing Carrier	1		45	046-0171	070166	Gasket Unloader Cover	1
5	046-0168	070163	Gasket Front Cap	1		46	048-0081	720002	Piston-HP	1
6	059-0166	110117	Capscrew Hex M8X20	21		47	051-0055	050122	Insert Rod-Bearing Half	4
7	046-0179	060068	Seal- Shaft	1		48	043-0100	727001	Valve Assembly-HP Inlet	2
8	051-0054	050172	Bearing Set Rear	1		49	046-0177	090095	Shim .015 Brg Adjustment	0
9	046-0227	070172	Gasket Rear Cap	1		49	046-0176	090094	Shim .010 Brg Adjustment	0
10	077-0071	728004	Centrifugal Adapter Plate	1		49	046-0175	090093	Shim .005 Brg Adjustment	0
11	044-0037	713002	Flywheel 16 7/8"	1		50	078-0011	728003	Plunge Unloader	1
12	059-0156	110104	Capscrew Skt HD M6X20	4		51	054-0175	719088	Set HP Piston Rings	1
13	060-0061	070201	Gasket Copper	14		52	052-0028	729006	Wristpin HP Piston	1
14	047-0054	705000	Rod Connecting	2		53	060-0072	130060	Lockwasher 10	4
15	043-0098	727000	Valve Assembly- LP Inlet	2		54	060-0063	070203	Gasket Copper	6
16	062-0006	160004	Plug-3/4" NPT	3		55	043-0094	727003	Spacer Inlet Valve	3
17	077-0069	020146	Cover Crankcase Side	1		56	136-0007	722007	Valve Safety 200 PSI ASME	1
18	054-0119	200100	Snapping Internal	2		57	043-0100	727002	Valve Assy HP/JP Discharge	2
19	052-0027	729000	Wristpin- LP Piston	1		58	059-0158	110106	Capscrew SKT Head 8X25	4
20	048-0054	720000	Piston LP 105mm	1		59	077-0073	727136	Cover Valve	3
21	054-0179	719064	Piston Ring Set LP	1		60	059-0154	110102	Capscrew SKT Head M10x45	4
22	046-0167	070162	Gasket Cylinder To Crankcase	1		61	058-0082	727134	Retainer Inlet Valve	2
23	059-0159	110107	Capscrew Hex 10 X 25	6		62	058-0083	727135	Retainer Discharge Valve	3
24	059-0167	110111	Capscrew Hex 12 X 70	8		63	060-0070	130058	Lockwasher 8	4
25	042-0005	150018	Bleeder line with fittings	1		64	063-0006	160002	Bushing Reducing 3/4"M x 1/4"F NPT	1
26	059-0163	110108	Capscrew Hex 16 X 80	1		65	059-0157	110105	Capscrew Hex M8x85	4
27	046-0166	070161	Gasket Cylinder Head	1		66	046-0172	070167	Gasket Aftercooler	2
28	042-0055	710000	Head Cylinder	1		67	046-0173	070169	Gasket Intercooler	2
29	055-0051	723003	Spring Unloader	1		68	043-0095	727004	Spacer Discharge Valve	2
30	062-0004	160005	Oil Drain Line-3/8" X4 "NPT	1		69	046-0174	070170	Gasket Valve Cover	3
31	058-0084	120058	Nut Adjustment Lock	1		70	060-0069	130057	Lockwasher 16	1
32	050-0030	711000	Cylinder	1		71	064-0022	160003	Elbow Street 90 Degrees 1/4"	2
33	019-0097	712000	Filter Inlet Assembly	1		72	060-0062	070202	Copper Valve Seat Gasket	5
34	019-0023	712114	Filter Element	1		73	077-0070	701029	Cap Rear	1
35	046-0169	070164	Gasket Side Cover	1		74	096-0009	728000	Weight Unloader	2
36	032-0031	731004	Flanged Sight Glass	1		75	107-0015	100100	Pin-Hinge	2
37	056-0018	703007	Breather	1		76	114-0012	728002	Holder Unloader	1
38	058-0086	120060	Nut Hex-M16	1		77	046-0183	070245	Gasket Set	1
39	146-0015	080029	Key Flywheel	1		78	042-0010	15017-CA2	Crank case vent line	1
40	082-0014	706004	Aftercooler	1		79	051-1999	511999	needle bearing wrist pin	2