





Clean out of Electric Auto Tank Drain



Steps to clean out the auto tank drain

1. Turn drain shut off ball valve to closed position
2. Slowly remove drain clean out cap
3. Remove drain filter screen
4. Clean drain filter screen
5. Slowly open drain ball valve with pressure in the tank to blow any debris that might be in the discharge flow path (Do not look at drain discharge during this step)
6. Close the drain ball valve
7. Re-install the drain screen and drain clean out cap
8. Open ball valve and push the test button on the drain to ensure proper function.

(Sometimes this has to be repeated 2-3 times)